

<http://www.winsystems.com>

MANUAL REVISION HISTORY

P/N G400-0385-000D (PCM-CAN-2-ISO, PCM-CAN-1-ISO)

Revision Date Code	ECO Number
140304	Initial Release

## TABLE OF CONTENTS

<b>BEFORE YOU BEGIN</b>	<b>4</b>
<b>Visual Index - Top View (Connectors &amp; Jumpers) - PCM-CAN-2-ISO</b>	<b>5</b>
<b>Visual Index - Top View (Connectors &amp; Jumpers) - PCM-CAN-1-ISO</b>	<b>6</b>
<b>Visual Index - Bottom View - PCM-CAN-x-ISO</b>	<b>7</b>
<b>INTRODUCTION</b>	<b>8</b>
<b>FEATURES</b>	<b>8</b>
System	9
Theory of Operation	9
<b>Jumper Reference</b>	<b>10</b>
JP3 - Base Address and Mode Selection	10
JP5 - Interrupt Selection	11
JP4 - Isolated Power Selection (Channel A)	12
JP6 - Termination (Channel A)	12
JP2 - Isolated Power Selection (Channel B)	13
JP1 - Termination (Channel B)	13
<b>CONNECTOR REFERENCE</b>	<b>14</b>
<b>Controller Area Network (CAN)</b>	<b>14</b>
J3, J7 - CAN A	14
J2, J6 - CAN B	14
<b>PC/104 BUS</b>	<b>15</b>
J1, J4 - PC/104	15
<b>SPECIFICATIONS</b>	<b>16</b>
<b>MECHANICAL DRAWING</b>	<b>17</b>
<b>APPENDIX - A</b>	<b>18</b>
BEST PRACTICES	18
<b>WARRANTY INFORMATION</b>	<b>22</b>

## BEFORE YOU BEGIN

WinSystems offers best practice recommendations for using and handling WinSystems products. These methods include valuable advice to provide an optimal user experience and to prevent damage to yourself and/or the product.

YOU MAY VOID YOUR WARRANTY AND/OR DAMAGE A PRODUCT BY FAILING TO COMPLY WITH THESE BEST PRACTICES.


Reference [Appendix - A](#) for **Best Practices**.



**Please review these guidelines carefully and follow them to ensure you are successfully using your product.**

For any questions you may have on WinSystems products, contact our Technical Support Group at (817) 274-7553, Monday through Friday, between 8 AM and 5 PM Central Standard Time (CST).

## Visual Index - Top View (Connectors & Jumpers) - PCM-CAN-2-ISO




RESERVED - J5

**NOTE:** The reference line to each component part has been drawn to Pin 1, and is also highlighted with a square, where applicable.




## Visual Index - Top View (Connectors & Jumpers) - PCM-CAN-1-ISO



RESERVED - J2, J5, J6, JP1, JP2

**NOTE:** The reference line to each component part has been drawn to Pin 1, and is also highlighted with a square, where applicable.

## Visual Index - Bottom View - PCM-CAN-x-ISO



## INTRODUCTION

This manual is intended to provide the necessary information regarding configuration and usage of the PCM-CAN-2-ISO and PCM-CAN-1-ISO modules. WinSystems maintains a Technical Support Group to help answer questions not adequately addressed in this manual. Contact Technical Support at (817) 274-7553, Monday through Friday, between 8 AM and 5 PM Central Standard Time (CST).

## FEATURES

### **CAN Module**

- Two NXP SJA-1000 CAN controllers (PCM-CAN-2-ISO)
  - Single channel version available (PCM-CAN-1-ISO)
- Transfer rates up to 1 Mbps
- Compliant with CAN specifications 2.0A (11-bit ID) and 2.0B (29-bit ID)
- Channel-to-channel and channel-to-system isolation
- Isolation on the CAN data connection up to 1000V
- On-board isolated 1W power supply for interface
- Jumper selectable termination resistors
- Jumper selectable IRQ and I/O base address
- Software drivers available for Linux and Windows®
- Custom OEM configurations available
- RoHS compliant

### **Industrial Operating Temperature**

- -40°C to 85°C

### **Power**

- +5V required

### **Mechanical**

- PC/104-compliant
- Dimensions: 3.6 x 3.8 inches (90 x 96 mm)
- Weight: 2.4 oz (68g)



## System

The PCM-CAN is a PC/104-compliant, Control Area Network (CAN) peripheral module. The PCM-CAN-2-ISO board uses two Philips/NXP SJA-1000 CAN controller ICs with advanced features for use in automotive and industrial applications. The PCM-CAN-1-ISO board is a single channel version based on the design.

CAN is a serial, asynchronous, multi-master communication protocol for connecting electronic control modules, sensors and actuators in automotive and industrial applications. The signal is encoded in a non-return-to-zero (NRZ) pattern and is sensed by all nodes. The CAN bus physical interface is similar to RS-485 two-wire, half-duplex communications.

## Theory of Operation

The PCM-CAN card uses high speed data isolation, transformer isolated power supplies, and custom logic to provide independent and user accessible isolated Control Area Network (CAN) interface(s). Each CAN controller occupies either 32 or 128 adjacent I/O registers depending on CAN 2.0A (BasicCAN) or CAN 2.0B (PeliCAN) mode selection. Additionally, when two CAN controllers are present, they share a single user configurable interrupt. There is no provision for separating the two controller's interrupts on the PCM-CAN board. This is important when writing a driver or ISR, since it is necessary for the program to read both CAN controllers to determine which controller was the source of the interrupt.

Each channel has an independent, on-board, isolated +5V DC power supply. Jumpers are provided to route power to or from the CAN interface connectors. Each channel can provide up to 150 mA of +5V power to the CAN interface and the transceivers must be powered by either the internal or an external source.

## Jumper Reference

NOTE: Jumper Part# SAMTEC 2SN-BK-G is applicable to all jumpers. These are available in a five piece kit from WinSystems (Part# KIT-JMP-G-200).

### JP3 - Base Address and Mode Selection

#### JP3

A15	1	<input checked="" type="checkbox"/>	2
A14	3	<input type="checkbox"/>	4
A13	5	<input type="checkbox"/>	6
A12	7	<input type="checkbox"/>	8
A11	9	<input type="checkbox"/>	10
A10	11	<input type="checkbox"/>	12
A9	13	<input checked="" type="checkbox"/>	14
A8	15	<input type="checkbox"/>	16
A7	17	<input type="checkbox"/>	18
A6	19	<input type="checkbox"/>	20
A5	21	<input type="checkbox"/>	22
A4	23	<input type="checkbox"/>	24

**Factory Setting**  
Address 0200 and CAN 2.0A shown.

**JP3** is used to select the base address and operation mode of the CAN controller(s). **JP3:1-22** represent the upper ISA address lines with an installed jumper equivalent to a binary 1. The user should set these jumpers to the desired binary base address of the CAN controller(s). A few examples are in the table below for clarity.

JP3 - Base Address Examples											
1-2	3-4	5-6	7-8	9-10	11-12	13-14	15-16	17-18	19-20	21-22	Jumper
A15	A14	A13	A12	A11	A10	A9	A8	A7	A6	A5	Address
-	-	-	-	-	-	-	X	-	-	-	0x0100 Hex
-	-	-	-	-	-	-	X	X	-	-	0x0180 Hex
-	-	-	-	-	-	X	-	-	-	-	0x0200 Hex
-	-	-	-	-	-	X	X	-	-	-	0x0300 Hex
X	-	X	-	-	-	-	-	-	-	-	0x0A00 Hex


**X = Jumper Installed**

Jumper location **JP3:23-24** sets the CAN controller(s) operational mode. The module is configured for CAN 2.0A (BasicCAN) mode operation from the factory, requiring 32 adjacent I/O registers per controller. To enable CAN 2.0B (PeliCAN) mode, requiring 128 adjacent I/O registers per controller, a jumper should be installed at **JP3:23-24**.

CAN 2.0A Mode Address Example	
Base Address = 0x0A00 Hex	
CAN Controller A	0x0A00Hex
↓	↓
CAN Controller A	0x0A1F Hex
CAN Controller B	0x0A20 Hex
↓	↓
CAN Controller B	0x0A3F Hex

CAN 2.0B Mode Address Example	
Base Address = 0x0A00 Hex	
CAN Controller A	0x0A00Hex
↓	↓
CAN Controller A	0x0A7F Hex
CAN Controller B	0x0A80 Hex
↓	↓
CAN Controller B	0x0AFF Hex


## JP5 - Interrupt Selection



**JP5** is the interrupt selection jumper used to set the desired interrupt used by the CAN controllers. Dual controllers share an interrupt. An installed jumper represents binary 1. The user should set these jumpers to represent the desired binary IRQ number.

IRQ Selection (JP5)			
D <sub>3</sub> , D <sub>2</sub> , D <sub>1</sub> , D <sub>0</sub>	Interrupt	D <sub>3</sub> , D <sub>2</sub> , D <sub>1</sub> , D <sub>0</sub>	Interrupt
0000	-	1000	-
0001	-	1001	IRQ9
0010	-	1010	IRQ10
0011	IRQ3	1011	IRQ11
0100	IRQ4	1100	IRQ12
0101	IRQ5	1101	-
0110	IRQ6	1110	IRQ14

## JP4 - Isolated Power Selection (Channel A)



### Factory Setting

**JP4** is used to connect isolated power to the Channel A CAN transceiver and interface connectors. The CAN transceiver can be powered from the on-board isolated +5V DC by installing jumpers at **JP4:1-2** and **JP4:3-4**. Additionally, the on-board isolated +5V DC and isolated ground can be routed to connectors **J3** and **J7** by installing jumpers at **JP4:5-6** and **JP4:9-10**.

The Channel A CAN transceiver can be powered by an external +5-12V DC source through connectors **J3** and **J7**. **Only jumpers JP4:5-6 and JP4:7-8 should be installed when powering the CAN transceiver from an external source.**




**CAUTION:** Incorrectly configuring the isolated power source can damage the module.

JP4 - Isolated Power Connections Channel A					
1-2	3-4	5-6	7-8	9-10	Jumper
X	X	-	-	-	Supply +5V to Transceiver
X	X	X	-	X	Supply +5V to Transceiver and Connectors ( <b>J3</b> and <b>J7</b> )
-	-	X	X	-	Receive +5 to +12V from <b>J3</b> or <b>J7</b>

**X = Jumper Installed**

## JP6 - Termination (Channel A)

### JP6




**CAUTION:** An improperly terminated CAN bus can result in reduced data rates, node capacity and bus length.

120Ω termination resistor for Channel A	1-2 or 2-3
No termination resistor for Channel A	OPEN

**JP6** is used to insert or remove a 120Ω termination resistor for CAN Channel A. Installing the jumper in either of the two possible positions (1-2 or 2-3) will result in placing a 120Ω resistor across the CAN differential transceiver pins. The end user must review the CAN bus system topology to determine whether this termination is desired. Typically, this termination is only required when the node is at either end of a bus. Other locations on the bus do not normally require termination.

## JP2 - Isolated Power Selection (Channel B)



**JP2** is used to connect isolated power to the Channel B CAN transceiver and interface connectors. The CAN transceiver can be powered from the on-board isolated +5V DC by installing jumpers at **JP2:1-2** and **JP2:3-4**. Additionally, the on-board isolated +5V DC and isolated ground can be routed to connectors **J2** and **J6** by installing jumpers at **JP2:5-6** and **JP2:9-10**.

The Channel B CAN transceiver can be powered by an external +5-12V DC source through connectors **J2** and **J6**. **Only jumpers JP2:5-6 and JP2:7-8 should be installed when powering the CAN transceiver from an external source.**




**CAUTION:** Incorrectly configuring the isolated power source can damage the module.

JP2 - Isolated Power Connections Channel B					
1-2	3-4	5-6	7-8	9-10	Jumper
X	X	-	-	-	Supply +5V to Transceiver
X	X	X	-	X	Supply +5V to Transceiver and Connectors (J2 and J6)
-	-	X	X	-	Receive +5 to +12V from J2 or J6

X = Jumper Installed

## JP1 - Termination (Channel B)



**CAUTION:** An improperly terminated CAN bus can result in reduced data rates, node capacity and bus length.

120Ω termination resistor for Channel B	1-2 or 2-3
No termination resistor for Channel B	OPEN

**JP1** is used to insert or remove a 120Ω resistor for CAN Channel B. Installing the jumper in either of the two possible positions (1-2 or 2-3) will result in placing a 120Ω resistor across the CAN differential transceiver pins. The end user must review the CAN bus system topology to determine whether this termination is desired. Typically, the termination is only required when the node is at either end of a bus. Other locations on the bus do not normally require termination.



# CONNECTOR REFERENCE

## Controller Area Network (CAN)

### J3, J7 - CAN A



PCB Connector: TEKA SRC205C425M126-0 (J3, J7)  
Mating Connector: ITW-PANCON 050-010-455A

#### J3, J7

VCC_A	1 ■ □ 2	GND_A
CANA_L	3 □ □ 4	CANA_H
GND_A	5 □ □ 6	NC
NC	7 □ □ 8	VCC_A
NC	9 □ □ 10	NC

Connectors **J3** and **J7** are configured in parallel and provide connection to **CAN Channel A**. Either **J3** or **J7** can be used to access **Channel A** or both can be used to daisy chain the bus through the module. The interface is wired to two 10-pin 0.100 inch right angle headers. WinSystems offers an optional cable [CBL-123-G-1-1.0](#), which provides a standard DB9 interface connector.

### J2, J6 - CAN B



PCB Connector: TEKA SRC205C425M126-0 (J2, J6)  
Mating Connector: ITW-PANCON 050-010-455A

#### J2, J6

VCC_B	1 ■ □ 2	GND_B
CANB_L	3 □ □ 4	CANB_H
GND_B	5 □ □ 6	NC
NC	7 □ □ 8	VCC_B
NC	9 □ □ 10	NC

Connectors **J2** and **J6** are configured in parallel and provide connection to **CAN Channel B**. Either **J2** or **J6** can be used to access **Channel B** or both can be used to daisy chain the bus through the module. The interface is wired to two 10-pin 0.100 inch right angle headers. WinSystems offers an optional cable [CBL-123-G-1-1.0](#), which provides a standard DB9 interface connector.

PCB Connector: **TEKA PC232-A-1A7-M (J1)**  
**TEKA PC220-A-1A7-M (J4)**

The PC/104 bus is electrically equivalent to the 16-bit ISA bus. Standard PC/104 I/O cards can be stacked on PCM-CAN-2-ISO and PCM-CAN-1-ISO's connectors, located at **J1** and **J4**. The interface does not support hot swap capability. The PC/104 bus connector pin definitions are provided below for reference. Refer to the [PC/104 Bus Specification](#) for specific signal and mechanical specifications.

<b>J4 (C/D)</b>			<b>J1 (A/B)</b>		
GND	<b>D0</b> ■ □ <b>C0</b>	GND	IOCHK#	<b>A1</b> ■ □ <b>B1</b>	GND
MEMCS16#	<b>D1</b> □ □ <b>C1</b>	SBHE#	SD7	<b>A2</b> □ □ <b>B2</b>	RESET
IOCS16#	<b>D2</b> □ □ <b>C2</b>	LA23	SD6	<b>A3</b> □ □ <b>B3</b>	+5V
IRQ10	<b>D3</b> □ □ <b>C3</b>	LA22	SD5	<b>A4</b> □ □ <b>B4</b>	IRQ
IRQ11	<b>D4</b> □ □ <b>C4</b>	LA21	SD4	<b>A5</b> □ □ <b>B5</b>	-5V
IRQ12	<b>D5</b> □ □ <b>C5</b>	LA20	SD3	<b>A6</b> □ □ <b>B6</b>	DRQ2
IRQ15	<b>D6</b> □ □ <b>C6</b>	LA19	SD2	<b>A7</b> □ □ <b>B7</b>	-12V
IRQ14	<b>D7</b> □ □ <b>C7</b>	LA18	SD1	<b>A8</b> □ □ <b>B8</b>	SRDY#
DACK0#	<b>D8</b> □ □ <b>C8</b>	LA17	SD0	<b>A9</b> □ □ <b>B9</b>	+12V
DRQ0	<b>D9</b> □ □ <b>C9</b>	MEMR#	IOCHRDY	<b>A10</b> □ □ <b>B10</b>	KEY
DACK5#	<b>D10</b> □ □ <b>C10</b>	MEMW#	AEN	<b>A11</b> □ □ <b>B11</b>	SMEMW#
DRQ5	<b>D11</b> □ □ <b>C11</b>	SD8	SA19	<b>A12</b> □ □ <b>B12</b>	SMEMR#
DACK6#	<b>D12</b> □ □ <b>C12</b>	SB9	SA18	<b>A13</b> □ □ <b>B13</b>	IOW#
DRQ6	<b>D13</b> □ □ <b>C13</b>	SD10	SA17	<b>A14</b> □ □ <b>B14</b>	IOR#
DACK7#	<b>D14</b> □ □ <b>C14</b>	SD11	SA16	<b>A15</b> □ □ <b>B15</b>	DACK3#
DRQ7	<b>D15</b> □ □ <b>C15</b>	SD12	SA15	<b>A16</b> □ □ <b>B16</b>	DRQ3
+5V	<b>D16</b> □ □ <b>C16</b>	SD13	SA14	<b>A17</b> □ □ <b>B17</b>	DACK1#
MASTER#	<b>D17</b> □ □ <b>C17</b>	SD14	SA13	<b>A18</b> □ □ <b>B18</b>	DRQ1
GND	<b>D18</b> □ □ <b>C18</b>	SD15	SA12	<b>A19</b> □ □ <b>B19</b>	REFRESH#
GND	<b>D19</b> □ □ <b>C19</b>	KEY	SA11	<b>A20</b> □ □ <b>B20</b>	BCLK
			SA10	<b>A21</b> □ □ <b>B21</b>	IRQ7
			SA9	<b>A22</b> □ □ <b>B22</b>	IRQ6
			SA8	<b>A23</b> □ □ <b>B23</b>	IRQ5
			SA7	<b>A24</b> □ □ <b>B24</b>	IRQ4
			SA6	<b>A25</b> □ □ <b>B25</b>	IRQ3
			SA5	<b>A26</b> □ □ <b>B26</b>	DACK2#
			SA4	<b>A27</b> □ □ <b>B27</b>	TC
			SA3	<b>A28</b> □ □ <b>B28</b>	BALE
			SA2	<b>A29</b> □ □ <b>B29</b>	+5V
			SA1	<b>A30</b> □ □ <b>B30</b>	OSC
			SA0	<b>A31</b> □ □ <b>B31</b>	GND
			GND	<b>A32</b> □ □ <b>B32</b>	GND

# = Active Low Signal


#### NOTES:

1. Rows C and D are not required on 8-bit modules.
2. B10 and C19 are key locations. WinSystems uses key pins as connections to GND.
3. Signal timing and function are as specified in ISA specification.
4. Signal source/sink current differ from ISA values.

## SPECIFICATIONS

MODELS		PCM-CAN-2-ISO PCM-CAN-1-ISO	
Electrical (Inputs)			
VCC		+5VDC ±5% @ 500 mA typical (PCM-CAN-2-ISO) +5VDC ±5% @ 250 mA typical (PCM-CAN-1-ISO)	
Channel A and B External Isolated Power		+5VDC to +12VDC	
Electrical (Outputs)			
Output	V <sub>OUT</sub>	I <sub>OUT</sub>	
Channel A Isolated Output	+5VDC	150 mA	
Channel B Isolated Output	+5VDC	150 mA	
MTBF	124.86 years  MTBF based on MIL-HDBK-217 Part Count Reliability Model assuming a ground benign operating environment, 30°C ambient operating temperature and 50°C junction temperatures.		
Mechanical			
Dimensions	3.6 x 3.8 inches (90 x 96 mm)		
Weight	2.4 oz (68g) PCM-CAN-2-ISO 2.2 oz (62g) PCM-CAN-1-ISO		
Printed Circuit Board	0.078 inches 4-Layer FR4		
Environmental			
Operating Temperature	-40°C to 85°C ambient		
Random Vibration	MIL-STD-202G, Method 214A, Condition D .1g/Hz (11.95g rms), 20 minutes per axis, 3 axis		
Mechanical Shock	MIL-STD-202G, Method 213B, Condition A 50g half-sine, 11 ms duration per axis, 3 axis		

MECHANICAL DRAWING



PCM-CAN MECHANICAL

## APPENDIX - A

### BEST PRACTICES

#### POWER SUPPLY

The power supply and how it is connected to the Single Board Computer (SBC) is very important.



##### **Avoid Electrostatic Discharge (ESD)**

Only handle the SBC and other bare electronics when electrostatic discharge (ESD) protection is in place. Having a wrist strap and a fully grounded workstation is the minimum ESD protection required before the ESD seal on the product bag is broken.

##### **Power Supply Budget**

Evaluate your power supply budget. It is usually good practice to budget 2X the typical power requirement for all of your devices.

##### **Zero-Load Power Supply**

Use a zero-load power supply whenever possible. A zero-load power supply does not require a minimum power load to regulate. If a zero-load power supply is not appropriate for your application, then verify that the single board computer's typical load is not lower than the power supply's minimum load. If the single board computer does not draw enough power to meet the power supply's minimum load, then the power supply will not regulate properly and can cause damage to the SBC.



##### **Use Proper Power Connections (Voltage)**

When verifying the voltage, you should always measure it at the power connector on the SBC. Measuring at the power supply does not account for voltage drop through the wire and connectors.

The single board computer requires +5V ( $\pm 5\%$ ) to operate. Verify the power connections. Incorrect voltages can cause catastrophic damage.

Populate all of the +5V and ground connections. Most single board computers will have multiple power and ground pins, and all of them should be populated. The more copper connecting the power supply to the single board computer the better.

##### **Adjusting Voltage**

If you have a power supply that will allow you to adjust the voltage, it is a good idea to set the voltage at the power connector of the SBC to 5.1V. The SBC can tolerate up to 5.25V, so setting your power supply to provide 5.1V is safe and allows for a small amount of voltage drop that will occur over time as the power supply ages and the connector contacts oxidize.


##### **Power Harness**

Minimize the length of the power harness. This will reduce the amount of voltage drop between the power supply and the single board computer.

##### **Gauge Wire**

Use the largest gauge wire that you can. Most connector manufacturers have a maximum gauge wire they recommend for their pins. Try going one size larger; it usually works and the extra copper will help your system perform properly over time.





### Contact Points

WinSystems' boards mostly use connectors with gold finish contacts. Gold finish contacts are used exclusively on high speed connections. Power and lower speed peripheral connectors may use a tin finish as an alternative contact surface. It is critical that the contact material in the mating connectors is matched properly (gold to gold and tin to tin). Contact areas made with dissimilar metals can cause oxidation/corrosion resulting in unreliable connections.

### Pin Contacts

Often the pin contacts used in cabling are not given enough attention. The ideal choice for a pin contact would include a design similar to Molex's or Trifurcons' design, which provides three distinct points to maximize the contact area and improve connection integrity in high shock and vibration applications.

## POWER DOWN

Make sure the system is **completely off/powering down** before connecting anything.



### Power Supply OFF

The power supply should always be off before it is connected to the single board computer.

### I/O Connections OFF

I/O Connections should also be off before connecting them to the single board computer or any I/O cards. Connecting hot signals can cause damage whether the single board computer is powered or not.

## MOUNTING AND PROTECTING THE SINGLE BOARD COMPUTER

### Do Not Bend or Flex the SBC

Never bend or flex the single board computer. Bending or flexing can cause irreparable damage. Single board computers are especially sensitive to flexing or bending around Ball-Grid-Array (BGA) devices. BGA devices are extremely rigid by design and flexing or bending the single board computer can cause the BGA to tear away from the printed circuit board.

### Mounting Holes

The mounting holes are plated on the top, bottom and through the barrel of the hole and are connected to the single board computer's ground plane. Traces are often routed in the inner layers right below, above or around the mounting holes.

Never use a drill or any other tool in an attempt to make the holes larger.

Never use screws with oversized heads. The head could come in contact with nearby components causing a short or physical damage.

Never use self-tapping screws; they will compromise the walls of the mounting hole.

Never use oversized screws that cut into the walls of the mounting holes.

Always use all of the mounting holes. By using all of the mounting holes you will provide the support the single board computer needs to prevent bending or flexing.

## MOUNTING AND PROTECTING THE SINGLE BOARD COMPUTER (continued)



### **Plug or Unplug Connectors Only on Fully Mounted Boards**

Never plug or unplug connectors on a board that is not fully mounted. Many of the connectors fit rather tightly and the force needed to plug or unplug them could cause the single board computer to be flexed.

### **Avoid cutting of the SBC**

Never use star washers or any fastening hardware that will cut into the single board computer.

### **Avoid Overtightening of Mounting Hardware**

Causing the area around the mounting holes to compress could damage interlayer traces around the mounting holes.

### **Use Appropriate Tools**

Always use tools that are appropriate for working with small hardware. Large tools can damage components around the mounting holes.

### **Placing the SBC on Mounting Standoffs**

Be careful when placing the single board computer on the mounting standoffs. Sliding the board around until the standoffs are visible from the top can cause component damage on the bottom of the single board computer.

### **Avoid Conductive Surfaces**

Never allow the single board computer to be placed on a conductive surface. Almost all single board computers use a battery to backup the clock-calendar and CMOS memory. A conductive surface such as a metal bench can short the battery causing premature failure.

## ADDING PC/104 BOARDS TO YOUR STACK

Be careful when adding PC/104 boards to your stack.

Never allow the power to be turned on when a PC/104 board has been improperly plugged onto the stack. It is possible to misalign the PC/104 card and leave a row of pins on the end or down the long side hanging out of the connector. If power is applied with these pins misaligned, it will cause the I/O board to be damaged beyond repair.

## CONFORMAL COATING

Applying conformal coating to a WinSystems product will not in itself void the product warranty, if it is properly removed prior to return. Coating may change thermal characteristics and impedes our ability to test, diagnose, and repair products. Any coated product sent to WinSystems for repair will be returned at customer expense and no service will be performed.

## OPERATIONS / PRODUCT MANUALS

Every single board computer has an Operations manual or Product manual.



### **Manual Updates**

Operations/Product manuals are updated often. Periodically check the WinSystems website (<http://www.winsystems.com>) for revisions.

### **Check Pinouts**

Always check the pinout and connector locations in the manual before plugging in a cable. Many single board computers will have identical headers for different functions and plugging a cable into the wrong header can have disastrous results.

### **Contact an Applications Engineer with questions**

If a diagram or chart in a manual does not seem to match your board, or if you have additional questions, contact your Applications Engineer.

## WARRANTY INFORMATION

(<http://www.winsystems.com/warranty.cfm>)

WinSystems warrants to Customer that for a period of two (2) years from the date of shipment any Products and Software purchased or licensed hereunder which have been developed or manufactured by WinSystems shall be free of any material defects and shall perform substantially in accordance with WinSystems' specifications therefore. With respect to any Products or Software purchased or licensed hereunder which have been developed or manufactured by others, WinSystems shall transfer and assign to Customer any warranty of such manufacturer or developer held by WinSystems, provided that the warranty, if any, may be assigned. Notwithstanding anything herein to the contrary, this warranty granted by WinSystems to the Customer shall be for the sole benefit of the Customer, and may not be assigned, transferred or conveyed to any third party. The sole obligation of WinSystems for any breach of warranty contained herein shall be, at its option, either (i) to repair or replace at its expense any materially defective Products or Software, or (ii) to take back such Products and Software and refund the Customer the purchase price and any license fees paid for the same. Customer shall pay all freight, duty, broker's fees, insurance charges for the return of any Products or Software to WinSystems under this warranty. WinSystems shall pay freight and insurance charges for any repaired or replaced Products or Software thereafter delivered to Customer within the United States. All fees and costs for shipment outside of the United States shall be paid by Customer. The foregoing warranty shall not apply to any Products or Software which have been subject to abuse, misuse, vandalism, accidents, alteration, neglect, unauthorized repair or improper installations.

THERE ARE NO WARRANTIES BY WINSYSTEMS EXCEPT AS STATED HEREIN, THERE ARE NO OTHER WARRANTIES EXPRESS OR IMPLIED INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN NO EVENT SHALL WINSYSTEMS BE LIABLE FOR CONSEQUENTIAL, INCIDENTAL OR SPECIAL DAMAGES INCLUDING, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF DATA, PROFITS OR GOODWILL. WINSYSTEMS' MAXIMUM LIABILITY FOR ANY BREACH OF THIS AGREEMENT OR OTHER CLAIM RELATED TO ANY PRODUCTS, SOFTWARE, OR THE SUBJECT MATTER HEREOF, SHALL NOT EXCEED THE PURCHASE PRICE OR LICENSE FEE PAID BY CUSTOMER TO WINSYSTEMS FOR THE PRODUCTS OR SOFTWARE OR PORTION THEREOF TO WHICH SUCH BREACH OR CLAIM PERTAINS.

### WARRANTY SERVICE

1. To obtain service under this warranty, obtain a return authorization number. In the United States, contact the WinSystems' Service Center for a return authorization number. Outside the United States, contact your local sales agent for a return authorization number.
2. You must send the product postage prepaid and insured. You must enclose the products in an anti-static bag to protect from damage by static electricity. WinSystems is not responsible for damage to the product due to static electricity.